



1515 MT. ROSE AVE. - York, PA 17403  
Phone: (717) 846-1632 Fax: (717) 854-9486 E-mail: sales@stahlheaders.com

### 2-1/8" Pro 2.0 Kit Instructions Big Block Chevrolet and 460 Ford

This header kit was prototyped on a Big Block Chev engine installed in a Ness/Bickle Pro type car with strut front suspension. This kit may be adapted to other chassis of similar design.

The following recommendation is intended as a guideline only. DO NOT accept it as the gospel and then call us and say "I cut off the amount you told me and now I find I cut off too much because I followed your instruction." When modifying tubes use care, caution, and judgement. If you have to cut off tubing we suggest going in no more than 1" increments until you are sure you have the correct offset and then tack the whole header together.

DO NOT remove the band from the tubes. It will help keep the pipes in alignment. The kit was bent intending to have material removed from the flange end of each tube.

Cylinder	Cut from A (flange) end	Cut between A & B curve
#1	2-1/2"	
#3	2-3/8"	
#5	2-3/8"	7/8" - Rotate to fit
#7	2-1/4"	2-1/8" - Rotate approx. 180°
#2	2-1/2"	
#4	2-3/8"	
#6	2-3/8"	7/8" - Rotate to fit
#8	2"	2-1/4" - Rotate to fit

Primary tube lengths are basically determined by the RPM range in which the engine will operate. Basically the following chart will get you in the ballpark.

Primary tube length	Max engine RPM range
32"	7000 to 8000
30"	8000 to 8500
28"	8500 to 9000
26"	9000 to 9500

*Used By The Country's Quickest And Fastest*